

**123 Manual, LP-288ai V2.0 TURBO OFDM Compact outdoor radio with throughput booster.  
INSTALLATION IN CLIENT MODE WITH FIRMWARE V2.0.2B5P1**

LP288aiV22B5\_M123\_ENC01W



**123 Manual, LP-288ai V2.0  
TURBO OFDM Compact Outdoor  
Radio With Throughput Booster,  
INSTALLATION IN CLIENT MODE  
WITH FIRMWARE V2.0.2B5P1**

**IMPORTANT NOTE:** The LP-288ai V2.0 equipment with firmware (V2.0.2B5P1) can be connected to equipment with identical firmware only. If you want to interconnect another equipment different from the AP LP-288ai V2.0 with firmware (V2.0.2B5P1) you must substitute the firmware for the V2.0.1B2P4 or V2.0.3B5POT2E1 version.

**1**

Check the content of the box, as shown in **Figure 1**.



Figure 1

**2**

Prepare the cable with the connector, as shown in **Figures 2-1, 2-2 and 2-3**.




Figure 2-1



Figure 2-2



Figure 2-3

**3**

Connect the cable, as shown in **Figure 3**.



Figure 3

## 4

Connect the LP-288ai to the POE, as shown in **Figure 4**.



Figure 4

## 5

Connect your PC or switch to the POE of your LP-288ai, as shown in **Figure 5**.




Figure 5

## 6

Connect to electric power, as shown in **Figure 6**.



Figure 6

## 7

Go to the properties of your network card and select **Internet Protocol (TCP/IP)** and then select **Properties**, as shown in Figure 7.




Figure 7

## 8

Select **Use the following IP address** and type an IP address in the LP-288ai V2.0 IP range by default; for this example we have selected the 192.168.1.201 address. The LP-288ai V2.0 has the 192.168.1.2 address by default. In **Subnet mask** type 255.255.255.0 and in **Default gateway** enter the address of the destination router. In the **DNS** you shall enter the DNS server, so the corresponding queries will be sent to the same DNS in the web, as shown in Figure 8.

Once you have finished, select **OK** twice.




Figure 8

## 9

Open the web browser of your preference and type the default address **192.168.1.2**, as shown in Figure 9.




Figure 9

10

It is important to mention that in this LP-288ai V2.0 configuration, it will be a client of the destination network. You shall take the following diagram as a guide. **Figure 10.** For this version of firmware, the connection will be feasible using a LP-288ai with the same firmware. Please see **Important Note** on page 12.




Figure 10

In this diagram, the destination network is the yellow one. There you have a router that provides Internet connection and it has the addresses delivery enabled in the 192.168.1.x segment, having reserved the addresses remaining from the scope. Such router will only deliver addresses from 100 to 200 and provides Internet connection. The blue segment is the network of your LP-288ai, where the router 100-200 shall have the 192.168.1.3 address.

**Important note:** In this example we are configuring the client which is the LP-288ai in the blue area of the diagram.

11

Open the web browser of your preference and type the default address 192.168.1.2, as shown in **Figure 11.**




Figure 11

12

In the window shown in **Figure 12**, the equipment will request a user and a password. The LP-288ai has two user levels, one with all the privileges, which is **super** by default with **super** as password, and another one with fewer privileges with **admin** as user and **admin** as password. Type **super** in user and password and select **OK**.





Figure 12

**13**


In the window shown in **Figure 13**, select **Basic/IP Configuration** and change the IP address for 192.163.1.3 for this example. Save changes by selecting **Update**.



**Figure 13**

**14**


Once you have saved the changes, select **Reboot** in the window shown in **Figure 14** so they will be effective.



**Figure 14**

**15**


The equipment will indicate it is rebooting and applying the changes, as shown in **Figure 15**.



**Figure 15**

**16**


Open the web browser of your preference and type the new address 192.168.1.3, as shown in **Figure 16**.



**Figure 16**

**17**


In the window of **Figure 17**, the equipment will request the user and the password again. Type **super** in both fields and select **OK**.



**Figure 17**

**18**


In the window shown in **Figure 18**, select **Basic/Operation Mode** and then **Slave**. Enter the destination network **SSID**. In this LanPro LP-288ai example, put the channel of the destination AP in **Radio Frequency**. If you do not know it, you can select **SmartSelect**. **Disable WDS** option. Select **Update** to save changes.



**Figure 18**

**19**


The equipment will save the changes, but they won't be effective unless you reboot the equipment. To do so, select **Reboot** as shown in **Figure 19**. It is important to mention that the equipment can be configured to connect with the destination AP using **Remote MAC**. We recommend you to read the 123 Point to Point, Point to Multi-point (PtP/PtMP) modes manual (Document: LP288aiV22B5\_M123\_END01).



**Figure 19**

**20**


The equipment will indicate it is rebooting and applying the changes, as shown in **Figure 20**.



**Figure 20**

**21**

In the screen shown in **Figure 21**, select **Security Setting**. In **Security Mode** select the encryption mode. Remember you must enter the same encryption the destination AP has.




**Figure 21**



**22**


In the screen shown in **Figure 22** you shall enter the corresponding encryption phrase. Select **Update** to save changes. Remember it has to be the same encryption phrase of the AP.



**Figure 22**

**23**


Once you have saved the changes, you must select **Reboot** so the changes will be effective, as shown in **Figure 23**.



**Figure 23**

**24**

The equipment will indicate it is rebooting and applying the changes, as shown in **Figure 24**.



**Figure 24**

**25**

To verify the connectivity, run the Ping command in a command window toward the equipment IP it is connecting, in this case 192.163.1.2. To do so, select **start** o **inicio**, select **Run** o **ejecutar**, as shown in **Figures 25-1** and **25-2**. Type the cmd command in the corresponding field and select **OK**.




Figure 25-1




Figure 25-2

**26**

Type the **Ping** command followed by the IP of the destination equipment, in this case 192.163.1.2. Press **Enter** and you will see the answer of the destination equipment, as shown in **Figures 26-1** and **26-2**. In case you do not get an answer from the AP, check the channel, encryption, and phrase data which are described in steps **18**, **21**, and **22**.




Figure 26-1





Figure 26-2

**27**

**Important recommendation (optional):**

Proceed to change the passwords of the **admin** and **super** users of your equipment. To change **admin** password, select **Administration** and type the new password on the corresponding field, then select **Update**, as shown in **Figure 27**.


Figure 27



**28**

To make the change effective, select **Reboot**.


Figure 28



**29**

In **Figure 29** you can see the screen indicating the equipment is rebooting.


Figure 29



**30**


Proceed to change the password of user named **super**. Remember you have to be authenticated as user **super** to make this change. Select **Super User** option and type the new password, select **Update**, as shown in **Figure 30**.

Figure 30



**31**


To make the change effective, select **Reboot**, as shown in **Figure 31**.



**Figure 31**

**32**


A window indicating that the equipment is rebooting is displayed, as shown in **Figure 32**.



**Figure 32**

**33**

The equipment will request your user and password once again. Enter the value you changed and select **OK**, as shown in **Figure 33**.



**Figure 33**

**34**

**IMPORTANT NOTE:**

**For the V.2.0.2.B5P1 version of the firmware, the clients can be LP-288ai of this firmware version only. If your AP is not LP-288ai firmware V.2.0.2.B5P1, you must use the firmware V2.0.3B2P1 or V2.0.3BP0T2E1 version in the LP-288ai client. You can ask for it on the website [www.lanpro.com](http://www.lanpro.com) in Support section.**