

Resetting the LanPro LP-289ai Radio to factory settings.

LP289ai_M123_ENC02W



Resetting the LanPro LP-289ai Radio to factory settings.



1

Disconnect the power.

2

Remove the screws on the back cover of the LP-289ai, taking care not to damage the seal that makes it hermetic.

3

Find the switch shown in figure 1 as follows:

**4**

Please push the reset switch pressed and then connect the power supply again, you should keep it pushed for 30 seconds.

5

This will return the LP-289ai to factory settings.

6

Now you can close the equipment, taking care not to damage the seal.

Recommendation:

This procedure should be performed by an authorized technical support center. Incorrectly performing it could damage the equipment and making the warranty void.