

**123 Manual, LP-F22XXYYYBK Horizontal Fiber Optical Splice Closure.
Assembling Instructions**

LF22XXYYYBK_M123_ENB01W

**123 Manual, LP-F22XXYYYBK
Horizontal Fiber Optical Splice Closure.
Assembling Instructions.**

This 123 Manual will guide you step by step in the process of assembling Horizontal Fiber Optical Splice Closure **LP-F22XXYYYBK** by LanPro.

1 First prepare closure and accessories, as shown in **Figure 1**.




Figure 1

2 Prepare Installation Tools, as follows, **Figure 2**.



Figure 2

3 Strip optical cable, as shown in **Figure 3**.




Figure 3

4 Tighten the cable on the holder by cross screwdriver, as you can see in **Figure 4** bellow.



Figure 4

5 Fix the optical fiber to splice case, coil the rest of the optical fiber inside splice case base, and Fix the optical fiber to down body as shown, **Figures 5a and 5b**.




Figure 5a




Figure 5b

- 6 Fix the weld fiber optics to the in-and-out port of the fiber splice and Put splice tray cover on. As shown in **Figures 6a and 6b.**




Figure 6a




Figure 6b

- 7 Seal the unused ports by plugs, as shown in **Figure 7.** 8 Close the up shell. Tighten shells by bolts. **Figure 8.**




Figure 7



Figure 8

LanPro is continuously improving its products and reserves the right to change specifications and availability without prior notice.